

How does the Dutchstove VESUV work:



Burn the coals to a glow



Place the bottom of the Vesuv on to the glowing coals



Fill the VESUV




Put on the lid



Cover the lid with hot coals



Do not allow flames to appear, only hot coals as flames can damage the Vesuv



The cooking time is approx, 45 / 60 min.